



Ear Cushion: EC-TT3

70mm Leatherette Donut Style Ear Cushion with speaker mesh and fixing bracket

Remove the existing 50mm ear cushion by gently pulling the underside of the ear cushion away from the speaker collar.

1




2

Take the EC-TTC plastic bracket and place clip side down onto speaker collar, aligning the notch on the bracket with the recess in the speaker collar. Press each of the four hooks on the bracket so that they clip over the speaker holder and the bracket is firm.

Take the EC-TT3 70mm leatherette ear cushion and offer it up to the bracket, slipping the skirt of the ear cushion over the bracket.

3



4

Carefully pull the skirt of the ear cushion up and over the plastic bracket until the ear cushion is in place and completely covers the bracket.

